SAMSUNG

Owner's Instructions



Before operating the unit, please read this manual throughly, and retain for future reference.

FEATURES 1
SAFETY INSTRUCTIONS 2
DESCRIPTION OF PARTS 3
CONTROL PANEL 4
WASHING PROCEDURE 5
Fuzzy course 5
Soak course 5
Speedy course 5
MANUAL FUNCTIONS 6
INSTALLATION & MAINTENANCE 7
Environment 7
In case of pump-drained washer 7
Assembling the sound absorbing panel 7
Connecting the drain hose 7
Levelling 7
Connecting the water supply hose 7
Cleaning the magic filter 8
How to put the detergent in 8
How to add the fabric softener 8
How to clean the filter 8
TROUBLESHOOTING 8
SPECIFICATIONS

FEATURES

FUZZY CONTROL

Fuzzy control operates with best washing course
by sensing the washload like artificial intelligence.

TRANSPARENT WINDOW

This Transparent Window is the new concept to solve the curiosity
of users to see inside of washing machine while operation.
While operation, the laundry progress inside of washing machine can be checked by looking through the transparent window.

BOOMERANG PULSATOR

The Boomerang Pulsator helps water
and detergent to go through fabrics efficiently while providing both the powerful water action to clean larger and heavier clothes and the gentle water action to clean all delicates with less wear and tear on clothes.

WATERFALL FLOW

The Waterfall Flow injected from under the pulsator cascades
with full force back into the tub, pushing down any clothes that float right
under the water surface. It is this Waterfall Flow that enables this washing
machine to effectively wash large and heavy items, such as bluejeans and blankets.

MAGIC FILTER

This unique magic Filter ensures that all the lint inside the tub is captured
for top quality filtering results to deliver consistently effective cleaning
results.

SOFTENER DISPENSER

The Softener Dispenser releases the fabric softener at the appropriate
time when the last rinsing proceeds.

SAFETY INSTRUCTIONS

WARNING!

To reduce the risk of fire, electric shock, or injury to persons when using your appliance, take care to adhere to the following precautions.

- **Where an unearthed power cord is not fitted, be sure that the washer is grounded.**
  To avoid electrical shock use metal piping for the ground connection.
  Take care not to ground the washer to gas pipes or telephone cables due to the danger of explosion from lightning strikes.

- **During spinning, don't put your hand in the spin basket.**
  Because the spin basket is rotating at the high speed, rotating parts may injure your hand.

- **Openings must not be obstructed by carpeting when the washing machine is installed on a carpeted floor.**

- **Turn off water taps when the washer is not in use to avoid water pressure damage to the pump.**

- **To minimize the possibility of electric shock, unplug this appliance from the power supply or disconnect the washer at the household distribution panel by removing the fuse or switching off the circuit breaker before attempting any maintenance or cleaning.**

- **The appliance is not intended for use by young children or infirm persons without supervision.**

- **Young children should be supervised to ensure that they do not play with the appliance.**

- **If the power supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similary qualified person in order to avoid a hazard.**

- **Place clothes evenly into the washer as unevenly distributed laundry may cause excessive out-of-balance noise and vibration.**

- **Don't use excessively hot water. (50˚C or more)**
  Plastic parts may be deformed or damaged.
  Also, clothing may be deformed or bleached.

- **Before washing, check all pockets.**
  If nails or pins remain in pockets, they may damage the washer or clothes.

- **Don't press the control panel with a sharp object.**
  Panel damaged or malfunction may occur.

  If the control panel for this washer is damaged, it must be replaced by a repair shop appointed by the manufacturer, as special purpose tools are required.

- **Do not operate this appliance if it is damaged, malfunctioning, partially disassembled, or has missing or broken parts, including a damaged cord or plug.**

- **Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.**

- **The instructions for use shall specify the maximum mass or dry cloth in kg, for which the appliance is designed.**

- **If the appliance is supplied from a cord extension set or electrical portable outlet device the cord extension set or electrical portable outlet device should be positioned so it is not subject to splashing or ingress of moisture.**

DESCRIPTION OF PARTS



LID
Be sure to keep the lid closed during washing and spinning.

DETERGENT BOX

FABRIC SOFTENER DISPENSER

BLEACH INLET

MAGIC FILTER
Lint will be collected in the filter during washing.

FRONT CONTROL PANEL Option

ADJUSTABLE LEGS
Adjust the length of the legs when installing the washer.

WATER SUPPLY HOSE(HOT) Option

WATER SUPPLY HOSE (COLD)

DRAIN-HOSE (PUMP) Option

SPIN BASKET
Stainless Option

"BOOMERANG" PULSATOR

POWER CORD Option

SOUND ABSORPTION PANEL Option

GROUND LEAD Option
When the water pipe is metal, make sure to cover the end of the ground wire.

WATER DRAIN HOSE

CONTROL PANEL

① **POWER BUTTON**

Press this button once to operate.
Press once again to turn the washer off.

② **START/HOLD BUTTON**

Use to pause and restart the operation.
To change the washing procedure during operation, press this button to stop, and once again to restart after changing the procedure.

③ **FUNCTION SELECT BUTTON**

With every press of this button, the function changes;
FUZZY ➔ SOAK ➔ SPEEDY ➔ WASH ➔ RINSE➔ SPIN ➔ RINSE&SPIN➔ FUZZY

④ **WATER LEVEL SELECT BUTTON**

According to the washload,select the water level ; HIGH ➔ MED ➔ LOW ➔ HIGH

⑤ **WATER SUPPLY SELECT BUTTON** Option

As you press this button, the type of water is selected as follows.
COLD ➔ COLD+HOT➔ HOT➔ COLD

⑥ **FUNCTION INDICATOR LIGHT**

The function in use indicator shows the current function as a flashing symbol.
The light goes out at the end of the function.



WASHING PROCEDURE

Before starting washing, check the following;

Connect the water supply hose to the water tap. Leave a tap open.
Plug the power cord in. Make sure to lay down the drain hose.(In case no drain pump)

Put the laundry into the washer and add detergent,too.

Be careful not to overload. Use right detergent for the fabrics you are washing.

FUZZY COURSE

Selects the best washing course automatically.

1. Press the POWER Button to"ON".

2. Press the START/HOLD button.

Water level is selected automatically.
Washing,rinsing, and spinning follow.
If you want to pause, press the START/HOLD button again.You can change the course when paused.

3. Close the lid.

SOAK COURSE

The laundry is soaked in water so that the dirt can be eliminated completely.

1. Press the POWER button to "ON".

2. Press the FUNCTION select button once.

3. Press the START/HOLD button

Water level is selected automatically.
Washing,rinsing, and spinning follow.
If you want to pause, press the START/HOLD button again.You can change the course when paused.

4. Close the lid.

SPEEDY COURSE

Because washing is speedy, it is good for light or less stained laundry.

1. Press the POWER button to "ON".

2. Press the COURSE select button twice.

3. Press the START/HOLD button

Water level is selected automatically.
Washing, rinsing, and spinning follow.
If you want to pause, press the START/HOLD button again.You can change the course when paused.

4. Close the lid.

MANUAL FUNCTIONS

FUNCTION	BUTTON
WASH ONLY Press the POWER button. Press the FUNCTION SELECT button three times. Press the START/HOLD button once.	 Function Button ***Three times***
RINSE ONLY Press the FUNCTION button four times. Press the START/HOLD button once.	 Function Button ***Four times***
SPIN ONLY Press the FUNCTION button five times. Press the START/HOLD button once.	 Function Button ***Five times***
RINSE AND SPIN Press the FUNCTION button six times. Press the START/HOLD button once. Rinsing and spin drying follow.	 Function Button ***Six times***

INSTALLATION & MAINTENANCE

ENVIRONMENT

Leave some space
Maintain at least 10cm between the washer and the wall.

Place the washer on a sturdy flat surface.
If the washer is placed on an uneven or weak surface, noise or vibration occurs. (Allowable is 1˚)

Adjust the legs for even placement.

Never install the washer near water.
Do not place the washer in steamy rooms or where the washer is directly exposed to rain.Moisture may destroy the electrical insulation causing an electrical shock hazard.

Avoid direct sunlight or heaters.
As plastic and electrical components are affected by direct heat,never place the washer near furnaces, boilers,etc. Do not place under direct sunlight.

IN CASE OF PUMP-DRAINED WASHER Option

- Take out the cap-hose and connect the outlet-hose.
- Be sure to join tightly the drain hose into the drain-outlet on theback of the machine.
- Install the drain hose in the position of about 70~80cm above the ground.



ASSEMBLING THE SOUND ABSORBING PANEL Option

Tilt the washer a little and lift up the panel until it clicks, filnaly fix the panel with screw to the base as shown in the figure.



CONNECTING THE DRAIN HOSE

After pressing the joint ring(a), insert the drain hose(b) to drain direction.



LEVELLING

SEE IF THE MACHINE IS PLACED LEVEL BY CHECKING THE POSITION OF THE WASHING TUB.

- Open the lid of the machine, pour water into the tub up to the level just below the pulsator, and adjust the legs so that the pulsator is positioned at the center of the water as shown in the figure.
- Place the machine more than 10cm away from the wall.



- Adjust the legs on feet for levelling .

CONNECTING THE WATER SUPPLY HOSE

1.Remove the adaptor from the water supply hose.





4.Connect the water supply hose to the adaptor. Pull down the part (c) of the water supply hose .When the part (c)is released, the hose is automatically connected to the adaptor making a 'click' sound.

2.First,using a "+" type screw driver, loosen the four screws on the adaptor. Next,take the adaptor and turn part(b) following the arrow for gap about 5mm between them.





5. Connect the other end of the water supply hose to the inlet water valve at the back of the washer. Screw the hose clockwise all the way in.

3. Connect adaptor to the water tap by tightening the screws firmly. Then, turn part (b) following the arrow and put (a) and (b)together.





If the water tap is a screw type,assemble a water supply hose that fits to the tap as shown.

NOTICE *After completing connection,if water leaks from the hose,then repeat the same steps.*
Use the most conventional type of faucet for water supply.
In case the faucet is square or too big,remove the spacing ring before inserting the faucet into the adaptor.

CLEANING THE MAGIC FILTER



1. Push the upper part of the filter and pull in.



2. Open the cover as shown in the figure.

3. Clean the filter.



4. Close the cover and insert t he lower part of the filter in the basket first and then push the filter with "click" sound .

HOW TO PUT THE DETERGENT IN

1. Open the detergent box by pulling in the direction of the arrow as shown in the figure and then put the powder detergent in the detergent box.
2. Put in one-time amount of detergent evenly so the detergent may not brim over the box.

HOW TO ADD THE FABRIC SOFTENER

- When a proper amount (one time does) of fabric softener is stored in the softener inlet,it is automatically put in at the last rinsing cycle.
- Do not use detergent, bleach or starch into the Softener Inlet.
- Using too much softener may produce unsatisfactory results.
- Do not open the lid during the Spin Dry cycle. If added too early, its effectiveness will decrease.
- Do not leave the softener into the Softener Dispenser for a long time. Because softner became stiff.

Pour it slowly

HOW TO CLEAN THE FILTER Option

1. Place a rag under the washer filter not to wet the floor.
2. Rotate the filter counterclockwise and pull out the filter.
3. Remove dirts and rotate the filter clockwise until it locks in position.



TROUBLESHOOTING

Washing machine won't work

Is the water tap opened?
Is the washer plugged in?
Is the power cut off?
Is there enough water?

Water dose not drain

Is the drain hose down?(No pump)
Is the drain hose frozen?
Is the drain hose clogged?
If the water dose not drain in 6 minutes, a buzzer will sound.

Water is not supplied

Is the water tap opened?
Is the water cut off?
Is the water supply hose or hose connection clogged?
Is the water tap frozen?
If water is not supplied in 1 hour,a buzzer will sound.

Spinning does not work

Is the laundry spread out evenly in the washer?
Is the washer set on a sturdy flat surface?

Power won't cut off

This sign means power is not cut off automatically.
Make sure there is lighting on the lamp whenever press the power button.



Water is overflowed

Restart after spinning.
If the error sign still indicates, call agency.

IN CASE THE NEED FOR SERVICING ARISES.

Don't hesitate to call any agency nearby with your name, address and telephone number when anything wrong with your product occurs.

SPECIFICATIONS

RATED POWER CONSUMPTION	WASH	300W	STANDARD WATER LEVEL	HIGH	58 *l*
	SPIN	240W		MED	50 *l*
DIMENSIONS		W540xD560xH850mm		LOW	37 *l*
WEIGHT		31kg	WATER USAGE		164 *l*
WATER PRESSURE		0.05~0.78 MPa (0.5 ~ 8.0 kg · f/cm^2)	PULSATOR ROTATING SPEED		126rpm
WASHING TYPE		Stirring Type	SPINNING TUB ROTATING SPEED		760rpm

CODE NO. : DC68-00631A